

DIAGNOSTICS TESTS. SENSITIVITY, SPECIFICITY AND ROC CURVES

Curs d'Estadística Bàsica per a la Recerca Biomèdica

UEB – VHIR

Santiago Pérez-Hoyos. Ricardo Gonzalo

OUTLINE


1. Diagnosis. Diagnostics tests
2. Sensitivity and specificity
3. Predictive values. Prevalence
4. Likelihood ratio
5. Receiver operator characteristic curves


Diagnostic

"If we did this 333 times,
we'd be giving false hope to
332 people for approximately
four hours and we'd save
one life. Isn't that worth it?"




Diagnostic Process







Diagnostic Measures




Diagnostic Measures




Diagnostic Measures



Diagnostic Measures



Diagnostic Measures




Relationship between the results of the test and the authentic diagnosis

In a diagnostic test with possible results:

- Positive or Negative: Diagnostic table (contingency table)
- Numerical values: ROC curve

		Reference method		TOTAL
		Sick	Healthy	
Diagnostic Test	Positive	a	b	a+b
	Negative	c	d	c+d
	TOTAL	a+c	b+d	a+b+c+d



1. Diagnosis. Diagnostics tests

		Reference method		TOTAL
		Sick	Healthy	
Diagnostic Test	Positive	a	b	a+b
	Negative	c	d	c+d
	TOTAL	a+c	b+d	a+b+c+d

a = True positives (TP)
 b = False positives (FP)
 c = False negative (FN)
 d = True negative (TN)

Example

Sample: n= 2.641 patients with suspected prostate cancer


1st test: rectal examination


Reference method: prostate biopsy

		Biopsy result		
		Disease	Healthy	TOTAL
Rectal examination	Disease	634	269	903
	Healthy	487	1251	1738
	TOTAL	1121	1520	2641





Sensitivity = $634 / (634 + 487) = 0.5656 = 56.6\%$  43.4% with cancer had a normal rectal examination

Specificity = $1251 / (269 + 1251) = 0.8230 = 82.3\%$

 17.7% of the patients without disease were incorrectly diagnosed

 **Other tests are needed to refine the diagnosis (Ex. PSA)**

Example with R Commander. Plug-in “EZR”



Example with R Commander. Plug-in “EZR”


	Disease positive	Disease negative	Total
Test positive	634	269	903
Test negative	487	1251	1738
Total	1121	1520	2641

Point estimates and 95 % CIs:


	Estimation	Lower CI	Upper CI
Apparent prevalence	0.342	0.324	0.360
True prevalence	0.424	0.406	0.444
Sensitivity	0.566	0.536	0.595
Specificity	0.823	0.803	0.842
Positive predictive value	0.702	0.671	0.732
Negative predictive value	0.720	0.698	0.741
Diagnostic accuracy	0.714	0.696	0.731
Likelihood ratio of a positive test	3.196	2.835	3.603
Likelihood ratio of a negative test	0.528	0.492	0.567

Positive/Negative predictive value


If the test is positive which is the probability the patient is really infected



Diagnostic Measures



Diagnostic Measures



Sensitivity

Test +

Disease

% False negative

Test -

% False Positive

Test +

Specificity

Test -

- Predictive Value

Test -

Test -

+

Test -



PPV, NPV Example with R Commander. Plug-in "EZR"

	Disease positive	Disease negative	Total
Test positive	634	269	903
Test negative	487	1251	1738
Total	1121	1520	2641

Point estimates and 95 % CIs:

	Estimation	Lower CI	Upper CI
Apparent prevalence	0.342	0.324	0.360
True prevalence	0.424	0.406	0.444
Sensitivity	0.566	0.536	0.595
Specificity	0.823	0.803	0.842
Positive predictive value	0.702	0.671	0.732
Negative predictive value	0.720	0.698	0.741
Diagnostic accuracy	0.714	0.696	0.731
Likelihood ratio of a positive test	3.196	2.835	3.603
Likelihood ratio of a negative test	0.528	0.492	0.567


PPV, NPV with more prevalence

	Disease positive	Disease negative	Total
Test positive	6340	259	6599
Test negative	4870	1251	6121
Total	11210	1510	12720

Point estimates and 95 % CIs:

	Estimation	Lower CI	Upper CI
Apparent prevalence	0.519	0.510	0.528
True prevalence	0.881	0.876	0.887
Sensitivity	0.566	0.556	0.575
Specificity	0.828	0.808	0.847
Positive predictive value	0.961	0.956	0.965
Negative predictive value	0.204	0.194	0.215
Diagnostic accuracy	0.597	0.588	0.605
Likelihood ratio of a positive test	3.297	2.948	3.688
Likelihood ratio of a negative test	0.524	0.508	0.541

PPV & NPV depend on prevalence



<u>Sen Spe</u>		<u>Sen Spe</u>	
—	ppv_99_99	- - -	npv_99_99
—	ppv_95_90	- - -	npv_95_90
—	ppv_95_50	- - -	npv_95_50
—	ppv_85_99	- - -	npv_85_99

Dependence of PPV and NPV on disease prevalence

Example: VIH diagnosis of two populations with RCommander

Compute positive and negative predictive values

Pretest probability: 0.0021
Sensitivity(0-1): 0.995
Specificity(0-1): 0.995

OK Cancel

```
> predictive.value
```

	Assumptions
Pretest probability	0.0021
Sensitivity	0.995
Specificity	0.995

	Estimated
Positive predictive value	0.295
Negative predictive value	1

Compute positive and negative predictive values

Pretest probability: 0.29
Sensitivity(0-1): 0.99
Specificity(0-1): 0.99


OK Cancel

```
> predictive.value
```


	Assumptions
Pretest probability	0.29
Sensitivity	0.99
Specificity	0.99

	Estimated
Positive predictive value	0.976
Negative predictive value	0.996

Diagnostic Measures



Diagnostic Measures



Sensitivity

Test +

Disease

% False negative

Test -

Likelihood Ratio -

% False negative

% False Positive

Test +

Specificity

Specificity

Test -




LR+,LR-Example with R Commander. Plug-in "EZR"

	Disease positive	Disease negative	Total
Test positive	634	269	903
Test negative	487	1251	1738
Total	1121	1520	2641

Point estimates and 95 % CIs:

	Estimation	Lower CI	Upper CI
Apparent prevalence	0.342	0.324	0.360
True prevalence	0.424	0.406	0.444
Sensitivity	0.566	0.536	0.595
Specificity	0.823	0.803	0.842
Positive predictive value	0.702	0.671	0.732
Negative predictive value	0.720	0.698	0.741
Diagnostic accuracy	0.714	0.696	0.731
Likelihood ratio of a positive test	3.196	2.835	3.603
Likelihood ratio of a negative test	0.528	0.492	0.567

LR+ & LR- do NOT depend on prevalence




Sen Spe		Sen Spe	
—	lrp_99_99	—	lrp_95_90
—	lrp_95_50	—	lrp_85_99
- - -	lrn_99_99	- - -	lrn_95_90
- - -	lrn_95_50	- - -	lrn_85_99

Interpretation:

- Positive Likelihood Ratio (LR+)
- LR+ over 5 - 10: Significantly increases likelihood of the disease
- LR+ between 0.2 to 5 (esp if close to 1): Does not modify the likelihood of the disease
- LR+ below 0.1 - 0.2: Significantly decreases the likelihood of the disease

Diagnostic Measures



Test +

Sensitivity

Accuracy=% classified right

Test +

+

Test -

% False negative

Test -

Disease

+

Healthy

% False Positive


Test +

Specificity

Test -



Diagnostic Measures



Test +

Sensitivity

Youden's Index =
sensitivity + specificity - 1

Test -

% False negative

Test +

% False Positive

Test -



Specificity

$$\frac{\text{Red Box}}{\text{Blue Oval}} + \frac{\text{Purple Box}}{\text{Purple Oval}} - 1$$





Accuracy depend on prevalence

Youden's Index do NOT depend on prevalence



Diagnostic Measures in R Commander



Enter Two-Way Table for Evidence Based ...

Enter counts:

	1	2
1	90	20
2	10	80

Compute Percentages

☐ Row percentages

☐ Column percentages

☐ Percentages of total

☒ No percentages

Hypothesis Tests

☒ Chi-square test of independence

☐ Components of chi-square statistic

☐ Print expected frequencies

☐ Fisher's exact test

Options

Digits

2

Medical indicators

☐ Prognosis

☒ Diagnosis

☐ Therapy

Help OK Cancel

	Disease	Non Disease	Total
Biomarker +	90	20	110
Biomarker -	10	80	90
Total	100	100	200

Sensitivity (Se) = 90 (95% CI 82.38 - 95.1) %

Specificity (Sp) = 80 (95% CI 70.82 - 87.33)%

Diagnostic accuracy (% of all correct results) = 85 (95% CI 79.28- 89.65) %.

Youden's index = 0.7 (95% CI 0.53 - 0.82).


Likelihood ratio of a positive test = 4.5 (95% CI 3.02 - 6.7).

Likelihood ratio of a negative test = 0.12 (95% CI 0.07 - 0.23).

Positive predictive value = 81.82 (95% CI 73.33 - 88.53) %.

Negative predictive value = 88.89 (95% CI 80.51- 94.54) %.

Number needed to diagnose = 1.43 (95% CI 1.21 - 1.88)



Enter Two-Way Table for Evidence Based ...

Enter counts:

	1	2
1	90	200
2	10	800

Compute Percentages

☐ Row percentages
☐ Column percentages
☐ Percentages of total
☒ No percentages

Hypothesis Tests

☒ Chi-square test of independence
☐ Components of chi-square statist
☐ Print expected frequencies
☐ Fisher's exact test

Options

Digits
2

Medical indicators

☐ Prognosis
☒ Diagnosis
☐ Therapy

Help OK Cancel

	Disease	Non Disease	Total
Biomarker +	90	200	290
Biomarker -	10	800	910
Total	100	1000	1100

Sensitivity (Se) = 90 (95% CI 82.38 - 95.1) %

Specificity (Sp) = 80 (95% CI 77.38 - 82.44)%

Diagnostic accuracy (% of all correct results) = 80.91 (95% CI 78.46 - 83.19) %.

Youden's index = 0.7 (95% CI 0.6 - 0.78).


Likelihood ratio of a positive test = 4.5 (95% CI 3.91 - 5.18).

Likelihood ratio of a negative test = 0.12 (95% CI 0.07 - 0.23).

Positive predictive value = 31.03 (95% CI 25.76 - 36.71) %.


Negative predictive value = 98.77 (95% CI 97.74 - 99.41) %.

Number needed to diagnose = 1.43 (95% CI 1.29 - 1.67).




Discrimination for quantitative test o biomarker

Sensitivity/Specificity



-
- If it is not a single biomarker or test you can build one by fitting a statistical model such as logistic regression
 - Select the best cutpoint to categorize biomarker or test in two groups (ROC Curve, Area Under Curve)
 - Proceed as before (Diagnostic Measures)

Receiver Operating Characteristic curves




Sensitivity vs false positive rate

Find best threshold for discrimination

(c-index) is the fraction of pairs (i,j) in which the predicted risk was higher for the subject who had the event:
 $C < 0.5$ No classification
 $C > 0.5$ Successful classification
 $C = 1$ perfect classification

Building of ROC curves



Example


Ultrasounds can be used to detect thinning of the uterus Wall (indicative of possible tumor). If the result is positive a biopsy is required

Cutoff for abnormal wall thickness	Sentivity (%)	Specificity (%)	1-Specificity(%)
>4 mm	99	50	50
>5 mm	97	61	39
>10 mm	83	80	20
>15 mm	60	90	10
>20 mm	40	95	5
>25 mm	20	98	2

Objetive: To maximize the number of VP (correct diagnosis of cancer) with an acceptable number of FP (biopsies made when there was no cancer)

Receiver operator characteristic curves (ROC)

- Example.



Regressio Multivariant logit per a mort_60

Number of obs = 51


VARIABLE		OR	(95%CI)	p-value
Dia 1 ST-2 >4153.60	No(<4153.60)	1		0.0095
	Si(>4153.60)	8.12	(1.67;39.60)	
APACHE II >26.00	No(<26.00)	1		0.0062
	Si(>26.00)	15.88	(2.19;114.85)	
Inmunosupresión previa	No	1		0.0254
	Sí	7.90	(1.29;48.43)	

LL model= -22.01 ; AIC model= 52.03 ; BIC model= 59.75

Detailed report of Sensitivity and Specificity

CUTPOINT	SENSITIVITY	SPECIFICITY	CORRECTED CLASSIFIED	LR+	LR-
(>= .0393311)	100.00%	0.00%	39.22%	1.0000	
(>= .244451)	95.00%	35.48%	58.82%	1.4725	0.1409
(>= .2496142)	80.00%	64.52%	70.59%	2.2545	0.3100
(>= .3939386)	75.00%	77.42%	76.47%	3.3214	0.3229
(>= .7244239)	65.00%	93.55%	82.35%	10.0750	0.3741
(>= .8370442)	45.00%	100.00%	78.43%		0.5500
(>= .8407952)	40.00%	100.00%	76.47%		0.6000
(>= .9766)	25.00%	100.00%	70.59%		0.7500
(> .9766)	0.00%	100.00%	60.78%		1.0000

Observaciones	ROC AREA	Std. Error	Asymptotic Normal [95% Conf. Interval]	Indice Youden	Punto corte según Youden	Mejor Punto corte AUC
51	0.8484	0.0585	0.7338 ; 0.9630	0.5855	0.72	0.39



ROC curves in R Commander

Formula de dades activa Statistical analysis Graphs and tables Eines Ajuda Original menu

diabetes

taula de dades Model: Σ <No hi ha cap model actiu>

- Discrete variables
- Continuous variables
- Tests no paramètrics
- Survival analysis
- Accuracy of diagnostic test
 - Accuracy of qualitative test
 - Kappa statistics for agreement of two tests
 - Compute positive and negative predictive values
 - ROC curve analysis for quantitative test**
 - Compare two ROC curves
 - Cronbach's alpha coefficient for reliability
- Matched-pair analysis
- Metaanalysis and metaregression
- Calculate sample size

ROC curve analysis for quantitative test

Response (encoded as 0 or 1) (pick one) Predictor (pick one)

BMI
CHD
DBP
ECG
EDAT
EDATDIAG
MORT
NUMPACIE
SBP
TABAC
TEMPSVIU

BMI
CHD
DBP
ECG
EDAT
EDATDIAG
MORT
NUMPACIE
SBP
TABAC
TEMPSVIU

☒ Show optimal threshold in graph

Direction for comparison

☒ Automatic

☐ \geq threshold as positive

☐ \leq threshold as positive

Optimal threshold

☒ Maximum sum of sensitivity + specificity

☐ Closest to the top-left corner

Supply weights if false positive and false negative predictions are not equivalent

Cost of false negative classification 1


Prevalence 0.5

Condition to limit samples for analysis. Ex1. age > 50 & Sex == 0 Ex2. age < 50 | Sex == 1

<all valid cases>

Ajuda Inicialitza D'acord Anul·la Aplica

ROC curve for edat



Compare ROC curve for edat and SBP

Compare two ROC curves

Response (encoded as 0 or 1) (pick one)

- BMI
- CHD
- DBP
- ECG
- EDAT
- EDATDIAG
- MORT
- NUMPACIE
- SBP
- TABAC
- TEMPSVIU

Predictor1 (pick one)

- BMI
- CHD
- DBP
- ECG
- EDAT
- EDATDIAG
- MORT
- NUMPACIE
- SBP
- TABAC
- TEMPSVIU

Predictor2 (pick one)

- BMI
- CHD
- DBP
- ECG
- EDAT
- EDATDIAG
- MORT
- NUMPACIE
- SBP
- TABAC
- TEMPSVIU

Condition to limit samples for analysis. Ex1. age > 50 & Sex == 0 Ex2. age < 50 | Sex == 1

< all valid cases >

Ajuda Inicialitza D'acord Anul·la Aplica

Compare ROC curve for edat and SBP

